

CP33 Well Installation

The CP33 should always be installed between the pump and the pressure switch. By doing this, there is always a consistent flow and pressure rate.

